

AgGPS® EZ-Guide® Plus lightbar guidance system

Upgrade Option Cabling Guide

**Version 2.01
Revision B
August 2006**



Corporate Office

Trimble Agriculture Division
10355 Westmoor Dr
Suite #100
Westminster, CO 80021
USA
www.trimble.com

Copyright and Trademarks

© 2005–2006, Trimble Navigation Limited. All rights reserved. Trimble, the Globe & Triangle logo, AgGPS, and EZ-Guide are trademarks of Trimble Navigation Limited, registered in the United States Patent and Trademark Office and in other countries. Autopilot and EZ-Steer are trademarks of Trimble Navigation Limited. Recon is a trademark of Tripod Data Systems Inc., a wholly owned subsidiary of Trimble Navigation Limited. All other trademarks are the property of their respective owners.

Release Notice

This is the August 2006 release (Revision A) of the *EZ-Guide Plus Lightbar Guidance System Upgrade Options Cabling Guide*. It applies to version 2.01 of the EZ-Guide Plus Lightbar Guidance System firmware. No part of this guide may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from Trimble Navigation Limited.

The following limited warranties give you specific legal rights. You may have others, which vary from state/jurisdiction to state/jurisdiction.

Hardware Limited Warranty

Trimble Navigation Limited warrants that this hardware product (the "Product") will perform substantially in accordance with published specifications and be substantially free of defects in material and workmanship for a period of two (2) years starting from the date of delivery. The warranty set forth in this paragraph shall not apply to software products.

Software License, Limited Warranty

This Trimble software product, whether provided as a stand-alone computer software product, built into hardware circuitry as firmware, embedded in flash memory, or stored on magnetic or other media, (the "Software") is licensed and not sold, and its use is governed by the terms of the relevant End User License Agreement ("EULA") included with the Software. In the absence of a separate EULA included with the Software providing different limited warranty terms, exclusions and limitations, the following terms and conditions shall apply. Trimble warrants that this Trimble Software product will substantially conform to Trimble's applicable published specifications for the Software for a period of ninety (90) days, starting from the date of delivery.

Warranty Remedies

Trimble's sole liability and your exclusive remedy under the warranties set forth above shall be, at Trimble's option, to repair or replace any Product or Software that fails to conform to such warranty ("Nonconforming Product") or refund the purchase price paid by you for any such Nonconforming Product, upon your return of any Nonconforming Product to Trimble in accordance with Trimble's standard return material authorization procedures.

Warranty Exclusions and Disclaimer

These warranties shall be applied only in the event and to the extent that: (i) the Products and Software are properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble's relevant operator's manual and specifications, and; (ii) the Products and Software are not modified or misused. The preceding warranties shall not apply to, and Trimble shall not be responsible for defects or performance problems resulting from (i) the combination or utilization of the Product or Software with hardware or software products, information, data, systems, interfacing or devices not made, supplied or specified by Trimble; (ii) the operation of the Product or Software under any specification other than, or in addition to, Trimble's standard specifications for its products; (iii) the unauthorized modification or use of the Product or Software; (iv) damage caused by accident, lightning or other electrical discharge, fresh or salt water immersion or spray; or (v) normal wear and tear on consumable parts (e.g., batteries). Trimble does not warrant or guarantee the results obtained through the use of the Product.

The warranties above state Trimble's entire liability, and your exclusive remedies, relating to performance of the products and software. Except as otherwise expressly provided herein, the products, software, and accompanying documentation and materials are provided "as-is" and without express or implied warranty of any kind by either Trimble Navigation Limited or anyone who has been involved in its creation, production, installation, or distribution including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, title, and noninfringement. The stated express warranties are in lieu of all obligations or liabilities on the part of Trimble arising out of, or in connection with, any products or software. Some states and jurisdictions do not allow limitations on duration or the exclusion of an implied warranty, so the above limitation may not apply to you.

TRIMBLE NAVIGATION LIMITED IS NOT RESPONSIBLE FOR THE OPERATION OR FAILURE OF OPERATION OF GPS SATELLITES OR THE AVAILABILITY OF GPS SATELLITE SIGNALS.

Limitation of Liability

Trimble's entire liability under any provision herein shall be limited to the amount paid by you for the product or software license. To the maximum extent permitted by applicable law, in no event shall Trimble or its suppliers be liable for any indirect, special, incidental or consequential damages whatsoever under any circumstance or legal theory relating in any way to the products, software and accompanying documentation and materials, (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss), regardless whether Trimble has been advised of the possibility of any such loss and regardless of the course of dealing which develops or has developed between you and Trimble. Because some states and jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

NOT WITHSTANDING THE ABOVE, IF YOU PURCHASED THIS PRODUCT OR SOFTWARE IN THE EUROPEAN UNION, THE ABOVE WARRANTY PROVISIONS MAY NOT APPLY. PLEASE CONTACT YOUR DEALER FOR APPLICABLE WARRANTY INFORMATION.

Notices

USA

Class B Statement – Notice to Users. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Changes and modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commission rules.

End User License Agreement

IMPORTANT, READ CAREFULLY. THIS END USER LICENSE AGREEMENT ("AGREEMENT") IS A LEGAL AGREEMENT BETWEEN YOU AND TRIMBLE NAVIGATION LIMITED and applies to the computer software provided with the Trimble product purchased by you (whether built into hardware circuitry as firmware, embedded in flash memory or a PCMCIA card, or stored on magnetic or other media), or provided as a stand-alone computer software product, and includes any accompanying printed materials and any "online" or electronic documentation ("Software"). The Software also includes any software (including, without limitation, upgrades and updates), that you download from Trimble's Web site. BY CLICKING "YES" IN THE ACCEPTANCE BOX, OR BY INSTALLING, COPYING OR OTHERWISE USING THE SOFTWARE, YOU AGREE TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNUSED SOFTWARE AND ACCOMPANYING TRIMBLE PRODUCT TO THE PLACE FROM WHICH YOU OBTAINED THEM FOR A FULL REFUND. This Software is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The Software is licensed, not sold.

1. SOFTWARE PRODUCT LICENSE

1.1 License Grant. This Agreement grants you a non-exclusive right to use one copy of the Software in a machine-readable form on any computer system. Such use is limited to use with Trimble products on any computer hardware and operating system for which it was intended. You may move the Software from one computer to another but may only use the Software on one computer at any time. If you are a business rather than an individual, you may authorize the personnel associated with your business to use the Software, but only one person at one time, on one computer at one time. You may also store or install a copy of the Software on a storage device, such as a network server, used only to install or run the Software on your other computers over an internal network; but in such case you must acquire and dedicate a license for each separate computer on which the Software is installed or run from the storage device. A license for the Software may not be shared or used concurrently on different computers.

1.2 Other Rights and Limitations. (1) The Software contains valuable trade secrets proprietary to Trimble and its suppliers. To the extent permitted by relevant law, you shall not, nor allow any third party to copy, decompile, disassemble or otherwise reverse engineer the Software, or attempt to do so, provided, however, that to the extent any applicable mandatory laws (such as, for example, national laws implementing EC Directive 91/250 on the Legal Protection of Computer Programs) give you the right to perform any of the aforementioned

activities without Trimble's consent in order to gain certain information about the Software for purposes specified in the respective statutes (i.e., interoperability), you hereby agree that, before exercising any such rights, you shall first request such information from Trimble in writing detailing the purpose for which you need the information. Only if and after Trimble, at its sole discretion, partly or completely denies your request, may you exercise such statutory rights. (2) This Software is licensed as a single product. You may not separate its component parts for use on more than one computer. (3) You may not rent, lease, or lend, the Software unless you are a reseller of Trimble products under separate written agreement with Trimble and authorized by Trimble to do so. (4) No service bureau work, multiple-user license or time-sharing arrangement is permitted. For purposes of this Agreement "service bureau work" shall be deemed to include, without limitation, use of the Software to process or to generate output data for the benefit of, or for purposes of rendering services to any third party over the Internet or other communications network. (5) You may permanently transfer all of your rights under this Agreement, provided you retain no copies, you transfer all of the Software (including all component parts, the media and printed materials, any upgrades, and this Agreement) and the recipient agrees to the terms of this Agreement. If the Software portion is an upgrade, any transfer must include all prior versions of the Software. (6) You may not export the Software or underlying technology in contravention of applicable U.S. and foreign export laws. (7) Without prejudice as to any other rights, Trimble may terminate this Agreement without notice if you fail to comply with the terms and conditions of this Agreement. In such event, you must destroy all copies of the Software and all of its component parts.

1.3 Copyright. All title and copyrights in and to the Software (including but not limited to any images, photographs, animations, video, audio, music, and text incorporated into the Software), the accompanying printed materials, and any copies of the Software are owned by Trimble and its suppliers. You shall not remove, cover or alter any of Trimble's patent, copyright or trademark notices placed upon, embedded in or displayed by the Software or on its packaging and related materials. You may, however, either (1) make one copy of the Software solely for backup or archival purposes, or (2) install the Software on a single computer provided you keep the original solely for backup or archival purposes. You may not copy the accompanying printed materials.

1.4 U.S. Government Restricted Rights. Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in this Agreement, and as provided in DFARS 227.7202-1(a) and 227.7202-3(a) (1995), DFARS 252.227-7013(c)(1)(ii) (OCT 1988), FAR 12.212(a) (1995), FAR 52.227-19, or FAR 52.227-14(ALT III), as applicable.

2. LIMITED WARRANTY.

2.1 Limited Warranty. Trimble warrants that the Software will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt. This limited warranty gives you specific legal rights, you may have others, which vary from state/jurisdiction to state/jurisdiction. The above limited warranty does not apply to error corrections, updates or upgrades of the Software after expiration of the ninety (90) day limited warranty period, which are provided "AS IS" and without warranty unless otherwise specified in writing by Trimble. Because the Software is inherently complex and may not be completely free of nonconformities, defects or errors, you are advised to verify your work. Trimble does not warrant that the Software will operate error free or uninterrupted, will meet your needs or expectations, or that all nonconformities can or will be corrected.

2.2 Customer Remedies. Trimble's and its suppliers' entire liability, and your sole remedy, with respect to the Software shall be either, at Trimble's option, (a) repair or replacement of the Software, or (b) return of the license fee paid for any Software that does not meet Trimble's limited warranty. This limited warranty is void if failure of the Software has resulted from accident, abuse, or misapplication. Any replacement Software will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

2.3 NO OTHER WARRANTIES. To the maximum extent permitted by applicable law, Trimble and its suppliers disclaim all other warranties and conditions, either express or implied, including but not limited to, implied warranties and conditions of merchantability and fitness for a particular purpose, title, and noninfringement with regard to the software and the provision of or failure to provide support services. To the extent allowed by applicable law, implied warranties and conditions on the software are limited to ninety (90) days. You may have other legal rights which vary from state/jurisdiction to state/jurisdiction.

2.4 LIMITATION OF LIABILITY. Trimble's entire liability under any provision of this Agreement shall be limited to the amount paid by you for the Software license. To the maximum extent permitted by applicable law, in no event shall Trimble or its suppliers be liable for any special, incidental, indirect or consequential damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use or inability to use the Software, or the provision of or failure to provide support services, even if Trimble has been advised of the possibility of such damages. Because some states and jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

2.5 PLEASE NOTE: If you have acquired this product from a dealer located in the European Union, the warranty provisions of this Section 2 will not apply. Please contact your dealer for applicable warranty information.

3. GENERAL.

3.1 This Agreement shall be governed by the laws of the State of California and applicable United States Federal law without reference to "conflict of laws" principles or provisions. The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement. Jurisdiction and venue of any dispute or court action arising from or related to this Agreement or the Software shall lie exclusively in or be transferred to the courts the County of Santa Clara, California, and/or the United States District Court for the Northern District of California. You hereby consent and agree not to contest, such jurisdiction, venue and governing law.

3.2 Section 3.1 notwithstanding, if you acquired this product in Canada, this Agreement is governed by the laws of the Province of Ontario, Canada. In such case each of the parties to this Agreement irrevocably attorns to the jurisdiction of the courts of the Province of Ontario and further agrees to commence any litigation that may arise under this Agreement in the courts located in the Judicial District of York, Province of Ontario. If you acquired this product in the European Union, this Agreement is governed by the laws of The Netherlands, excluding its rules governing conflicts of laws and excluding the United Nations Convention on the International Sale of Goods. In such case each of the parties to this Agreement irrevocably attorns to the jurisdiction of the courts of The Netherlands and further agrees to commence any litigation that may arise under this Agreement in the courts of The Hague, The Netherlands.

3.3 Trimble reserves all rights not expressly granted by this Agreement.

Contents

ii	Contents	v
1	Receiver Only	1
	AgGPS 110 GPS Receiver (With AgGPS EZ-Guide SL Cable)	1
	Without remote control	1
	With remote control	2
	AgGPS 114 GPS Receiver (With 40947-18 Cable)	3
	Without remote control	3
	With remote control	3
	AgGPS 110/114 GPS Receiver (With 30945 Cable)	4
	Without remote control	4
	With remote control	4
	AgGPS 124/132 GPS Receiver	5
	Without remote control	5
	With remote control	5
	AgGPS 252 GPS Receiver	6
	Without remote control	6
	With remote control	6
2	Steering Only	7
	AgGPS EZ-Steer™ assisted steering system	7
	AgGPS Autopilot™ Automated Steering System	8
3	Mapping Only	9
	AgGPS EZ-Map Software	9
	Pocket PC without remote control	9
	Pocket PC with remote control	10
	AgGPS® Recon™ handheld without remote control	10
	AgGPS Recon handheld with remote control	11
	AgGPS 170 Field Computer	12
	Without remote control	12
	With remote control	12
4	Receivers and Steering	13
	AgGPS 110 GPS Receiver (With EZ-Guide SL Cable) and EZ-Steer Assisted Steering System	13
	Without remote control	13
	With remote control	14
	AgGPS 114 GPS Receiver (With 40947-18 Cable) and EZ-Steer Assisted Steering System	15
	Without remote control	15
	With remote control	15
	AgGPS 110/114 GPS Receiver (With 30945 Cable) and EZ-Steer Assisted Steering System	16
	Without remote control	16
	With remote control	16

Contents

AgGPS 124/132 GPS Receivers and EZ-Steer Assisted Steering System	17
Without remote control.	17
With remote control	17
AgGPS 252 GPS Receiver and EZ-Steer Assisted Steering System	18
Without remote control.	18
With remote control	18
AgGPS 132 GPS Receiver and Autopilot Automated Steering System.	19
AgGPS 252 GPS Receiver and Autopilot Automated Steering System.	19
5 Receivers and Mapping	21
AgGPS 110 GPS Receiver With 46441 Cable and AgGPS EZ-Map Software	21
Pocket PC without remote control	21
Pocket PC with remote control	22
AgGPS Recon handheld without remote control	22
AgGPS Recon handheld with remote control	23
AgGPS 114 GPS Receiver With 40947-18 Cable and AgGPS EZ-Map Software	24
Pocket PC without remote control	24
Pocket PC with remote control	25
AgGPS Recon handheld without remote control	25
AgGPS Recon handheld with remote control	26
AgGPS 124/132 GPS Receiver and AgGPS EZ-Map Software	27
Pocket PC without remote control	27
Pocket PC with remote control	28
AgGPS Recon handheld without remote control	29
AgGPS Recon handheld with remote control	29
AgGPS 252 GPS Receiver and AgGPS EZ-Map Software	30
Pocket PC without remote control	30
Pocket PC with remote control	31
AgGPS Recon handheld without remote control	31
AgGPS Recon handheld with remote control	32
AgGPS 110 GPS Receiver (With EZ-Guide SL Cable) and AgGPS 170 Field Computer	33
Without remote control.	33
With remote control	34
AgGPS 114 GPS Receiver (With 40947-18 Cable) and AgGPS 170 Field Computer.	35
Without remote control.	35
With remote control	36
AgGPS 124/132 GPS Receiver and AgGPS 170 Field Computer.	37
Without remote control.	37
With remote control	38
AgGPS 252 GPS Receiver and AgGPS 170 Field Computer.	39
Without remote control.	39
With remote control	40
6 Steering and Mapping	41
EZ-Steer Assisted Steering System and AgGPS EZ-Map Software.	41

Pocket PC without remote control	41
Pocket PC with remote control	42
AgGPS Recon handheld without remote control	42
AgGPS Recon handheld with remote control	43
EZ-Steer Assisted Steering System and AgGPS 170 Field Computer	44
Without remote control.	44
With remote control	44
AgGPS Autopilot Automated Steering System and AgGPS EZ-Map Software.	45
Pocket PC.	45
AgGPS Recon handheld	46
7 Receivers and Steering and Mapping	47
AgGPS 110 GPS Receiver (With EZ-Guide SL Cable), EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software	47
Pocket PC without remote control	47
Pocket PC with remote control	48
AgGPS Recon handheld without remote control	48
AgGPS Recon handheld with remote control	49
AgGPS 114 GPS Receiver (With 40947-18 Cable), EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software	50
Pocket PC without remote control	50
Pocket PC with remote control	51
AgGPS Recon handheld without remote control	51
AgGPS Recon handheld with remote control	52
AgGPS 124/132 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software.	53
Pocket PC without remote control	53
Pocket PC with remote control	53
AgGPS Recon handheld without remote control	54
AgGPS Recon handheld with remote control	54
AgGPS 252 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software.	55
Pocket PC without remote control	55
Pocket PC with remote control	55
AgGPS Recon handheld without remote control	56
AgGPS Recon handheld with remote control	56
AgGPS 110 GPS Receiver (With EZ-Guide SL Cable), EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer	57
Without remote control.	57
With remote control	57
AgGPS 114 GPS Receiver (With 40947-18 Cable), EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer	58
Without remote control.	58
With remote control	59
AgGPS 124/132 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer	60
Without remote control.	60
With remote control	60


Contents

AgGPS 252 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer . . .	61
Without remote control.	61
With remote control	61
AgGPS 132 GPS Receiver, AgGPS Autopilot Automated Steering System, and AgGPS EZ-Map Software	62
Pocket PC.	62
AgGPS Recon handheld	63
AgGPS 252 GPS Receiver, Autopilot Automated Steering System, and AgGPS EZ-Map Software . .	64
Pocket PC.	64
AgGPS Recon handheld	65
8 Switch Inputs and Pulse Outputs.	67
Switch Inputs	67
With relay.	67
Pulse Outputs.	69


Receiver Only

AgGPS 110 GPS Receiver (With AgGPS EZ-Guide SL Cable)

Without remote control




With remote control




AgGPS 114 GPS Receiver (With 40947-18 Cable)

Without remote control




With remote control




AgGPS 110/114 GPS Receiver (With 30945 Cable)

Without remote control




With remote control




AgGPS 124/132 GPS Receiver

Without remote control




With remote control



AgGPS 252 GPS Receiver Without remote control




With remote control




Steering Only

AgGPS EZ-Steer™ assisted steering system




AgGPS Autopilot™ Automated Steering System




Mapping Only

AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS® Recon™ handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 170 Field Computer

Without remote control




With remote control




Receivers and Steering

AgGPS 110 GPS Receiver (With EZ-Guide SL Cable) and EZ-Steer Assisted Steering System

Without remote control




With remote control




AgGPS 114 GPS Receiver (With 40947-18 Cable) and EZ-Steer Assisted Steering System

Without remote control




With remote control




AgGPS 110/114 GPS Receiver (With 30945 Cable) and EZ-Steer Assisted Steering System

Without remote control




With remote control




AgGPS 124/132 GPS Receivers and EZ-Steer Assisted Steering System

Without remote control




With remote control




AgGPS 252 GPS Receiver and EZ-Steer Assisted Steering System


Without remote control




With remote control



AgGPS 132 GPS Receiver and Autopilot Automated Steering System




AgGPS 252 GPS Receiver and Autopilot Automated Steering System




Receivers and Mapping

AgGPS 110 GPS Receiver With 46441 Cable and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 114 GPS Receiver With 40947-18 Cable and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 124/132 GPS Receiver and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 252 GPS Receiver and AgGPS EZ-Map Software

Pocket PC without remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

Pocket PC with remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

AgGPS Recon handheld without remote control



Note – Cover (insulate) the unused power connector to avoid a short circuit.


AgGPS Recon handheld with remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

AgGPS 110 GPS Receiver (With EZ-Guide SL Cable) and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 114 GPS Receiver (With 40947-18 Cable) and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 124/132 GPS Receiver and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 252 GPS Receiver and AgGPS 170 Field Computer

Without remote control



Note – Cover (insulate) the unused power connector to avoid a short circuit.

With remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.


Steering and Mapping

EZ-Steer Assisted Steering System and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




EZ-Steer Assisted Steering System and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS Autopilot Automated Steering System and AgGPS EZ-Map Software

Pocket PC




AgGPS Recon handheld




Receivers and Steering and Mapping

AgGPS 110 GPS Receiver (With EZ-Guide SL Cable), EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 114 GPS Receiver (With 40947-18 Cable), EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software


Pocket PC without remote control




Pocket PC with remote control




AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control



AgGPS Recon handheld without remote control




AgGPS Recon handheld with remote control




AgGPS 252 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS EZ-Map Software

Pocket PC without remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

Pocket PC with remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

AgGPS Recon handheld without remote control



Note – Cover (insulate) the unused power connector to avoid a short circuit.


AgGPS Recon handheld with remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

AgGPS 110 GPS Receiver (With EZ-Guide SL Cable), EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 114 GPS Receiver (With 40947-18 Cable), EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 124/132 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer

Without remote control




With remote control




AgGPS 252 GPS Receiver, EZ-Steer Assisted Steering System, and AgGPS 170 Field Computer

Without remote control



Note – Cover (insulate) the unused power connector to avoid a short circuit.


With remote control




Note – Cover (insulate) the unused power connector to avoid a short circuit.

AgGPS 132 GPS Receiver, AgGPS Autopilot Automated Steering System, and AgGPS EZ-Map Software

Pocket PC




AgGPS Recon handheld




AgGPS 252 GPS Receiver, Autopilot Automated Steering System, and AgGPS EZ-Map Software

Pocket PC




AgGPS Recon handheld



Switch Inputs and Pulse Outputs


Switch Inputs

With relay







To connect wires to the external interface cable 3-way connector:

1. Strip 5.6 mm (7/32") of insulation from each wire on the external input device.
2. Thread each wire through a cable seal and then place the wire in a female crimp terminal.



Note – Position the cable seal flush with the end of the insulation, and in the large crimp tabs.

3. Use a crimp tool or pliers to crimp the female terminal. Solder the exposed wire to the female crimp terminal. Check the physical and electrical connection. Do not use an excessive amount of solder. Repeat for each wire termination.
4. Insert the three female crimp terminals and cable seals into the 3-way female connector housing. Ensure that each crimp terminal latches into the housing.
5. Lock the crimped wires into the connector by rotating the cover 90° as shown.
6. Plug the finished 3-way female connector into the 3-way male connector on the cable.



Pulse Outputs

The AgGPS® EZ-Guide® Plus lightbar guidance system with firmware version 2.00 or later uses GPS speed to generate a signal. This signal simulates the output of a radar speed gun for application rate controllers. Because some controllers need a stronger signal, an in-line pulse amplifier (P/N 56328) is included with radar simulator cables.

To install the pulse amplifier (P/N 56328) and use the radar pulses, use cable P/N 52033 and an appropriate radar cable for your equipment.

To install the pulse amplifier:

1. Plug the pulse amplifier into the 9-pin port on the EZ-Guide Plus lightbar.
2. Carefully tighten the two screws until they just hold the pulse amplifier in place.
3. Connect the external interface cable (P/N 52033) to the output of the pulse amplifier and then tighten the thumb screws.
4. Plug the remote control connector into the “KPAD” end of the external interface cable (P/N 52033).
5. Plug the radar cable into the 3-pin Delphi WeatherPack connector on the external interface cable.
6. Plug the radar cable into your rate controller in place of the radar gun.

