

# Universal Terminal

AGRICULTURE

July 2019

**TRIMBLE RESELLER CONFIDENTIAL**

## Universal Terminal

To use Universal Terminal (UT), make sure an ISO-certified implement is connected and **Universal Terminal** is enabled in the ISOBUS settings.

**Note:** On the Precision-IQ Home screen, tap the **Settings** button. On the Settings screen, tap **ISOBUS**, then activate the **Enable Universal Terminal** setting.

To launch the Universal Terminal:

Tap the **Universal Terminal** button on the Activity bar in Precision-IQ:



*or*

Tap the **Universal Terminal** icon on the Launcher screen:



From this terminal interface, you can control the ISO-certified implement using Universal Terminal.

## Universal Terminal Settings


On the UT screen, tap the Settings icon in the upper-right corner of the screen to configure the following settings:

<http://agpartners.trimble.com>


[www.trimble.com](http://www.trimble.com)

© 2019, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo are trademarks of Trimble Trimble Inc., registered in the United States and in other countries. Precision-IQ is a trademark/trademarks of Trimble Inc. All other trademarks are the property of their respective owners.

General Settings



Messaging



## For More Information

Contact your local Trimble Regional Sales Manager.