

Field Manager: Boundaries

AGRICULTURE

February 2019

TRIMBLE RESELLER CONFIDENTIAL

Field Manager: Boundaries

On the Field Manager screen, tap **Boundaries** for a view of boundaries that have been assigned to the field. On the left side of the screen, tap a boundary item to select it. Once selected, you can modify the boundary details: boundary name, delete boundary, and activate/deactivate boundary.

Tap the **Home** icon to return to the Home screen.

Boundary Name

Tap in the Boundary Name field to edit the name of the boundary.

Delete

Tap the **Delete** button to delete the boundary.

Note: This action cannot be undone.

Resize

Follow the steps below to expand or contract the boundary:

1. Tap the **Resize** button:




2. Tap the text box and use the on-screen number pad to enter the distance to move the boundary:

<http://agpartners.trimble.com>

www.trimble.com

© 2019, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo are trademarks of Trimble Trimble Inc., registered in the United States and in other countries. Precision-IQ is a trademark/trademarks of Trimble Inc. All other trademarks are the property of their respective owners.



To shift the boundary outward (making the area larger), tap **Expand**.

To shift the boundary inward (making the area smaller), tap **Contract**.

3. Tap the green check. The application saves a copy of the pattern with a new name at the new position.

Activate/Deactivate

Once created, a boundary is active by default.

- Tap **Deactivate** to deactivate the boundary. The map will update to show the boundary with a black line.
- Tap **Activate** to activate the boundary. An active boundary shows on the map with a red line.

For More Information

Contact your local Trimble Regional Sales Manager.