

System Diagnostics

AGRICULTURE

October 2019

TRIMBLE RESELLER CONFIDENTIAL

System Diagnostics

From the Precision-IQ activity bar, tap the **Diagnostics** icon to display the Diagnostics screen.

Performance

By default, the System's Devices Performance screen displays and shows the following information:

System Information	Description
Title	This column lists all devices managed by Precision-IQ.
Firmware Version	This column shows the installed firmware version for each connected device.
Serial Number	This column shows the serial number for each connected device.
Connected	This column shows whether or not a device which is managed by Precision-IQ is actually connected to the display.

This reference information is useful should you need to submit a support request.

Logging

Tap **Logging** for a summary of logging details. By default, the screen shows all system logs. Tap **Logging Level** to filter the system log report by:

Log Information	Description
Info	Show only informational details.
Warning	Show only warning details.
Error	Show only error details.
Assert	Show only assert details.
Fault	Show only fault details.

<http://agpartners.trimble.com>

www.trimble.com

© 2019, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo are trademarks of Trimble Inc., registered in the United States and in other countries. Precision-IQ is a trademark of Trimble Inc. All other trademarks are the property of their respective owners.

Tap the **Pause** button to suspend logging. While paused, the Pause button will slowly blink. Tap the **Pause** button again to resume logging.

For More Information

Contact your local Trimble Regional Sales Manager.